

Warming Drawer, 60cm

Series 9 | Minimal

Black



Keep plates warm until ready to serve; rapid proof or slow cook to perfection. Pair with an oven for matching Minimal styling.

- A companion product, designed to match with other Contemporary style Fisher & Paykel products
- Space to keep six standard-sized place settings evenly warm
- Easy to clean smooth-glass base
- Six versatile tailored programmes for warming, proofing, dehydrating and slow cooking

DIMENSIONS

| | |
|--------|-------|
| Height | 140mm |
| Width | 596mm |
| Depth | 567mm |

FEATURES & BENEFITS

Complementary design

Our Warming Drawer comes in either a stylish black reflective glass or brushed stainless steel, for seamless pairing with our matching ovens.

MULTI-FUNCTION FLEXIBILITY

Choose from six tailored functions including Rapid Proof, Dehydrate and Slow Cook.

EASY TO CLEAN

Cleaning and care of the Warming Drawer is simple. After each use, just wipe out the smooth glass interior with a damp cloth.

EASY TO USE

Handle-free, push-to-open with capacitive touch controls, our Warming Drawer gives you the freedom to keep plates or cups warm while you continue to cook.

PRECISE CONTROL

With fast and even heating, our warming drawer is great for keeping food warm and low temperature cooking, as well as resting after a traditional roast in the oven and proofing dough.

SAFE AND SOUND

With Automatic switch-off and Delayed start functionality, our warming drawers help keep dishes warm until it is time to serve the main meal.

SPECIFICATIONS

| | |
|-----------------|----|
| Capacity | 20 |
| Cappuccino cups | |

| | |
|----------------|-------|
| Espresso cups | 42 |
| Place settings | 6 |
| Usable depth | 408mm |
| Usable height | 98mm |
| Usable width | 535mm |

Cleaning

- Easy clean smooth-glass base

Controls

- Audio feedback
- Automatic pre-set
- Automatic timers **30', 45', 1h, 2h, 4h, 6h**
- Delayed start
- Electronic capacitive touch
- On/Off indicator
- Pre-set heating functions
- Push-to-open drawer
- Sabbath mode
- Standby mode

Functions

- Cups
- Dehydrate
- Number of functions **6**
- Plates
- Slow cook
- Warm

Performance

| | |
|---------------------------|-----------|
| Heated glass base and fan | • |
| Low temperature cooking | • |
| Temperature levels | 6 |
| Temperature range | 35°C-85°C |

specifications may change at any time. You should therefore check with Fisher & Paykel's Customer Care Centre to ensure this page correctly describes the model currently available. © Fisher & Paykel Appliances Ltd 2020

**A PEACE OF MIND SALE****24 Hours 7 Days a Week Customer Support****T 1300 650 590 W www.fisherpaykel.com****Power requirements**

| | |
|-------------------|--------|
| Amperage | 10A |
| Power cord length | 1800mm |
| Supply frequency | 50Hz |
| Supply voltage | 220V |

Product dimensions

| | |
|--------------------------------|-------|
| Adjustable front door panel to | • |
| Depth | 567mm |
| Height | 140mm |
| Width | 596mm |

Safety

| | |
|-----------------------------|---|
| Automatic turn off after 12 | • |
| Full extension slides | • |

Warranty

| | |
|------------------|---------|
| Parts and labour | 2 years |
|------------------|---------|

| | |
|-----|-------|
| SKU | 82191 |
|-----|-------|

The product dimensions and specifications in this page apply to the specific product and model. Under our policy of continuous improvement, these dimensions and