

# Installation Guide

ARCISAN

## Synergii Wall Faced Pan


SY04152 (Slim Seat) and SY04162 (Standard Seat)

Please leave the instructions with the owner.


The standard set-out for a S-Trap is 90mm.

All distances are from final floor or finished wall.

The pan is designed to be used with in-wall cistern AR04430.




1




Place the pan in position ensuring it is centred in accordance with the centre line of the outlet. Mark location of pan fixing bolts.

2




Remove pan, drill holes for fixing bolts and attach brackets.

3



For **S Trap installation**, cut horizontal pipe to required length and fit seal. Attach wall fixing kit to elbow, push elbow into the pan collar and adjust to correct height. Fix to wall and adjust to ensure the elbow is vertical.

4



Locate the pan in the final position. Screw threads into floor mount brackets.

streamline

This product installation must comply to AS/NZS 3500.

Dimensions are in millimeters and are subject to manufacturing variations. Streamline reserves the right to vary specifications at any time without notice. Information provided within this installation sheet is correct at the date of printing.

Version: 1.1 - August 2017